



INSTALLATION OF GEOTEXTILE SILT FENCE

1. EXCAVATE A 100 x 100 TRENCH IN A CRESENT SHAPE ACROSS THE FLOW PATH WITH ENDS POINTING UPSLOPE.
2. DRIVE STURDY STAKES, SPACED 3000 APART, INTO THE GROUND ALONG THE DOWNSLOPE SIDE OF THE TRENCH.
3. INSTALL THE FILTER FABRIC FROM A CONTINUOUS ROLL AND CUT TO REQUIRED LENGTH. THE FILTER FABRIC SHOULD BE STAPLED TO THE UPSTREAM SIDE OF THE STAKES, EXTENDING THE BOTTOM 200 INTO THE TRENCH.
4. BACKFILL AND COMPACT THE SOIL IN THE TRENCH OVER THE FILTER FABRIC.