



NOTES:

1. TOP OF SIGN BOARD 100 ABOVE TOP OF POST.
2. LAG BOLTS TO BE 80 x 10Ø GALVANIZED WITH GALVANIZED WASHERS.
3. MAXIMUM SPACING FOR LAG BOLTS IS 600.
4. CROSS MEMBERS TO BE ATTACHED TO POSTS USING 300 x 20 GALVANIZED NUTS AND WASHERS.
5. ALL LUMBER TO BE PRESSURE TREATED.



TRANSPORTATION AND WORKS
HIGHWAY DESIGN DIVISION

SIGN POST INSTALLATION DETAILS TYPE "D"

DRAWN BY: DEB KIRBY	DATE: REV 02-01-10	NOT TO SCALE
---------------------	--------------------	--------------

MARCH 2011

1293 -1